

Rear Tugger Application Chart

Note: not all bikes are listed - we just can't measure all bikes out there. So...

If your bike is not a KTM and has two rear seat mounting bolts, one on each side of the seat, get the Style 1.

If you have a KTM with the single under-seat bolt, get the Style 1 unless otherwise listed, but it mounts to the subframe stubs, NOT the seat mounting bolt!

If you have a newer (2021+) KTM, get the Style 1 unless otherwise listed, but it mounts to the subframe stubs, NOT the seat mounting bolts!

If you see your same model, but a different year, chances are good the style listed will work.

If you get one and it doesn't work, send it to us for a full refund.

If you are wondering about "Adjust length" column, it's just for us when we do custom embroidery.

Extra plastic spacers, aluminum spacers, or longer bolts need to be ordered separately

Make	Year	Model	Front Style	Rear Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Extra aluminum spacers?	Notes
Beta								
Beta	13-14	250RR	2 O, 2 EE, or 6	Style 1	16.5			
Beta	13-15	300RR	2 O, 2 EE, or 6	Style 1	16.5			
Beta	18-23	300RR	2 O, 2 EE, or 6	Style 1	17.0			
Beta	20-23	390RR-S	2 O, 2 EE, or 6	Style 1	17.0			
Beta	08	525	2 O, 2 EE, or 6	Style 1	12.0			
Beta	16	XTrainer	2 O, 2 EE, or 6	Style 3-4				
Beta	20-23	XTrainer	2 O, 2 EE, or 6	Style 1	15.0			
BMW								
BMW	09	G450X	2 O, 2 EE, or 6	Style 1	9.0			
BMW	07	G650X	2 O, 2 EE, or 6	Style 1	13.5			
Cannondale								
Can	03	E440	2 O, 2 EE, or 6	Style 1	8.5			
Cobra								
Cobra	07	CX50JR	2 O, 2 EE, or 6	Style 3-4				
GasGas								
GAS	24	MCE3	2 O, 2 EE, or 6	Style 3-4				
GAS	23	MC50	2 O, 2 EE, or 6	Style 3-4				
GAS	23-24	MC85	2 O, 2 EE, or 6	Style 1	16.0			
GAS	22-23	MC125	2 O, 2 EE, or 6	Style 1	21.0			
GAS	23	EC250	2 O, 2 EE, or 6	Style 1	22.0			
GAS	22-23	EX250	2 O, 2 EE, or 6	Style 1	22.0			
GAS	23	EX250F	2 O, 2 EE, or 6	Style 1	22.0			
GAS	23	MC250	2 O, 2 EE, or 6	Style 1	21.0			
GAS	22-23	MC250F	2 O, 2 EE, or 6	Style 1	21.0			
GAS	07-09	EC300	2 O, 2 EE, or 6	Style 1	10.0			
GAS	10-12	EC300	2 O, 2 EE, or 6	Style 1	16.0			
GAS	21-23	EC300	2 O, 2 EE, or 6	Style 1	22.0			
GAS	24	EC300	2 O, 2 EE, or 6	Style 1	18.0			
GAS	23	EX300	2 O, 2 EE, or 6	Style 1	22.0			
GAS	24	EX300	2 O, 2 EE, or 6	Style 1	16.0			
GAS	13	300RR	2 O, 2 EE, or 6	Style 1	16.0			
GAS		CAMI	2 O, 2 EE, or 6	Style 1	16.0			
GAS	18	XC300	2 O, 2 EE, or 6	Style 3-4				
GAS	23	EX350F	2 O, 2 EE, or 6	Style 1	22.0			
GAS	22-23	MC350F	2 O, 2 EE, or 6	Style 1	21.0			
GAS	06	EC450	2 O, 2 EE, or 6	Style 1	10.0			
GAS	22-23	EX450F	2 O, 2 EE, or 6	Style 1	22.0			
GAS	22-23	MC450F	2 O, 2 EE, or 6	Style 1	22.0			
GAS	24	EW500F	2 O, 2 EE, or 6	Style 1	18.0			
GAS	24	ES500	2 O, 2 EE, or 6	Style 1	18.0			
Honda								
Hon	00	XR50	2 O, 2 EE, or 6	Style 3-4				
Hon	04-23	CRF50F	2 O, 2 EE, or 6	Style 3-4				
Hon		XR70	2 O, 2 EE, or 6	Style 1	10.5			
Hon	04-07	CR70F	2 O, 2 EE, or 6	Style 3-4				
Hon	00	XR80	2 O, 2 EE, or 6	Style 1	16"			
Hon	04-13	CRF80F	2 O, 2 EE, or 6	Style 3-4				
Hon	99	CR80R	2 O, 2 EE, or 6	Style 1	11.5			
Hon	03-05	CR85R	2 O, 2 EE, or 6	Style 1	11.3			
Hon	06	CR85R/RE	2 O, 2 EE, or 6	Style 1	9.0			
Hon	04-13	CRF100F	2 O, 2 EE, or 6	Style 3-4				
Hon	13-17	CRF110F	2 O, 2 EE, or 6	Style 1	10.5			

Make	Year	Model	Front Style	Rear Style	Adjust Tugger length to ... inches	Extra plastic spacers?	Extra aluminum spacers?	Notes
Hon	18	CRF110F	2 O, 2 EE, or 6	Style 1	10.5			use M6x30 bolt, 3 plastic washers, stock spacer
Hon	20	CRF110F	2 O, 2 EE, or 6	Style 1	11.5			
Hon	96	XR100	2 O, 2 EE, or 6	Style 1	14.0			
Hon	03	XR100	2 O, 2 EE, or 6	Style 3-4				
Hon	97	CR125R	2 O, 2 EE, or 6	Style 1	11.0			
Hon	00	CR125R	2 O, 2 EE, or 6	Style 1	10.5			
Hon	02-03	CR125R	2 O, 2 EE, or 6	Style 1	11.0			
Hon	04-06	CR125R	2 O, 2 EE, or 6	Style 1	10.9			
Hon	15-18	CRF125F/FB	2 O, 2 EE, or 6	Style 3-4				Mount under seat; sandwich between seat and frame
Hon	19-24	CRF125F/FB	2 O, 2 EE, or 6	Style 1	11.5			
Hon	04-21	CRF150F	2 O, 2 EE, or 6	Style 3-4				
Hon	07-13	CRF150R	2 O, 2 EE, or 6	Style 1	12.0			
Hon	19-20	CRF150R	2 O, 2 EE, or 6	Style 1	12.0			
Hon	2001	XR200R	2 O, 2 EE, or 6	Style 3-4				
Hon	04-15	CRF230F	2 O, 2 EE, or 6	Style 3-4				
Hon	19	CRF230F	2 O, 2 EE, or 6	Style 3-4				
Hon	09	CRF230M	2 O, 2 EE, or 6	Style 1	15.0			street bike version
Hon	09	CRF230L	2 O, 2 EE, or 6	Style 1	15.0			street bike version
Hon	20	CRF250F	2 O, 2 EE, or 6	Style 3-4				
Hon	13-18	CRF250L	2 O, 2 EE, or 6	Style 1	11.0			seat mount=11"; rear mount=8.5"
Hon	04-12	CRF250X	2 O, 2 EE, or 6	Style 1	10.3			
Hon	04-06	CRF250R	2 O, 2 EE, or 6	Style 1	9.8			
Hon	07	CRF250R	2 O, 2 EE, or 6	Style 1	11.2			
Hon	08-13	CRF250R	2 O, 2 EE, or 6	Style 1	10.0			
Hon	14-16	CRF250R	2 O, 2 EE, or 6	Style 1	9.0		2	Best to use two shoulder spacers on each side
Hon	19-21	CRF250R	2 O, 2 EE, or 6	Style 1	9.0			
Hon	24	CRF250R	2 O, 2 EE, or 6					no clean solution identified
Hon	20-21	CRF250RX	2 O, 2 EE, or 6	Style 1	10.0			
Hon	22	CRF250RX	2 O, 2 EE, or 6	Style 3-4				
Hon	23	CRF250RX	2 O, 2 EE, or 6	Style 1	12.0			need to trim the plastic a bit
Hon	24	CRF250RX	2 O, 2 EE, or 6					No clean solution identified
Hon	94	CR250R	2 O, 2 EE, or 6	Style 1	11.0			
Hon	00-02	CR250R	2 O, 2 EE, or 6	Style 1	10.5			
Hon	03-04	CR250R	2 O, 2 EE, or 6	Style 1	11.0			
Hon	05-06	CR250R	2 O, 2 EE, or 6	Style 1	9.0			
Hon	03-04	XR250	2 O, 2 EE, or 6	Style 1	12.2			
Hon	21	CRF300L	2 O, 2 EE, or 6	Style 1	10.0			
Hon	01-04	XR400R	2 O, 2 EE, or 6	Style 1	12.2			
Hon	19	CRF450L	2 O, 2 EE, or 6	Style 1	11.0		2	M8x30 bolt, 3 plastic washers, 2 alum spacers each side
Hon	02-04	CRF450R	2 O, 2 EE, or 6	Style 1	11.0			
Hon	05-06	CRF450R	2 O, 2 EE, or 6	Style 1	9.8			
Hon	07	CRF450R	2 O, 2 EE, or 6	Style 1	10.8			
Hon	08-09	CRF450R	2 O, 2 EE, or 6	Style 1	10.0			
Hon	10-13	CRF450R	2 O, 2 EE, or 6	Style 1	9.0			
Hon	14-16	CRF450R	2 O, 2 EE, or 6	Style 1	9.0		2	Best to use two shoulder spacers on each side
Hon	17-18	CRF450R	2 O, 2 EE, or 6	Style 1	10.5			4 plastic & 1 alum spacer on each side, with M8x30 bolt
Hon	19-20	CRF450R	2 O, 2 EE, or 6	Style 1	10.5			M8x30 bolt, stock spacer, 3 or 4 plastic washers
Hon	22	CRF450R	2 O, 2 EE, or 6	Style 3-4				
Hon	23-24	CRF450R	2 O, 2 EE, or 6					No clean solution identified
Hon	21-23	CRF450RL	2 O, 2 EE, or 6	Style 1	10.5			M8x30 bolt, aluminum spacer, 3 or 4 plastic washers
Hon	20	CRF450RWE	2 O, 2 EE, or 6	Style 1	10.5			M8x30 bolt, stock spacer, 3 or 4 plastic washers
Hon	17-21	CRF450RX	2 O, 2 EE, or 6	Style 1	10.5	4		4 plastic & 1 alum spacer on each side, with M8x30 bolt
Hon	05	CRF450X	2 O, 2 EE, or 6	Style 1	9.8			
Hon	06-16	CRF450X	2 O, 2 EE, or 6	Style 1	10.8			
Hon	19-24	CRF450X	2 O, 2 EE, or 6	Style 1	10.5		2	Use 2 alum spacers and 3-4 plastic washers on each side, with M8x30 bolts
Hon	95-00	CR500	2 O, 2 EE, or 6	Style 1	13.0			
Hon	01, 05	XR650R	2 O, 2 EE, or 6	Style 1	11.5			
Hon	05-21	XR650L	2 O, 2 EE, or 6	Style 1	18.0			
Husaberg								
Husa	06	FE550E	2 O, 2 EE, or 6	Style 1	12.0			
Husa	09	FE450	2 O, 2 EE, or 6	Style 1	12.0			
Husa	2013	FE350	2 O, 2 EE, or 6	Style 1	12.0			
Husqvarna								
Husq	21	EE5	2 O, 2 EE, or 6	Style 3-4				

Make	Year	Model	Front Style	Rear Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Extra aluminum spacers?	Notes
Husq	23	EE3	2 O, 2 EE, or 6	Style 3-4				
Husq	17	TC50	2 O, 2 EE, or 6	Style 5				
Husq	18-20	TC50	2 O, 2 EE, or 6	--				no obvious clean solution - ingenuity required... Might want to notch the right side fendor because of exhaust pipe
Husq	21	TC50	2 O, 2 EE, or 6	Style 3-4				
Husq	17	TC65	2 O, 2 EE, or 6	Style 5				
Husq	18	TC65	2 O, 2 EE, or 6	--				no obvious clean solution - ingenuity required...
Husq	20-23	TC65	2 O, 2 EE, or 6	--				no obvious clean solution - ingenuity required...
Husq	15-17	TC85	2 O, 2 EE, or 6	Style 1	14.0			
Husq	18	TC85	2 O, 2 EE, or 6	Style 3-4				
Husq	21-24	TC85	2 O, 2 EE, or 6	--				no obvious clean solution - ingenuity required...
Husq	06	CR125	2 O, 2 EE, or 6	Style 1	10.0			
Husq	17	TC125	2 O, 2 EE, or 6	Style 5				
Husq	19-22	TC125	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to -M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	23	TC125	2 O, 2 EE, or 6	Style 3-4				Use M6 x 16 bolts
Husq	24	TC125	2 O, 2 EE, or 6	Style 1	19.0			See pic for hardware
Husq	15	TE125	2 O, 2 EE, or 6	Style 1	14.0			Use a small aluminum spacer on each side
Husq	09	WR125	2 O, 2 EE, or 6	Style 1	12.0			
Husq	17	TE150	2 O, 2 EE, or 6	Style 5				
Husq	20-22	TE150i	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to -M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	24	TE150	2 O, 2 EE, or 6	Style 1	19.0			
Husq	14	FC250	2 O, 2 EE, or 6	Style 1	14.0			Use a small aluminum spacer on each side
Husq	16-18	FC250	2 O, 2 EE, or 6	Style 5				
Husq	20	FC250	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to -M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	23-24	FC250	2 O, 2 EE, or 6	Style 1	19.0			See pic for hardware. '23 is the same as '24
Husq	17-19	FE250	2 O, 2 EE, or 6	Style 5				
Husq	06	TC250	2 O, 2 EE, or 6	Style 1	10.0			
Husq	10	TC250	2 O, 2 EE, or 6	Style 1	12.0			
Husq	16	TC250	2 O, 2 EE, or 6	Style 1	15.0			
Husq	17	TC250	2 O, 2 EE, or 6	Style 5				
Husq	19-22	TC250	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to -M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	24	TC250	2 O, 2 EE, or 6	Style 1	19.0			See pic for hardware
Husq	12	TCX250	2 O, 2 EE, or 6	Style 1	10.0			compatible with TC, TXC and WR with this body style - many years; just haven't measured them all
Husq	06	TE250	2 O, 2 EE, or 6	Style 1	10.0			
Husq	14	TE250	2 O, 2 EE, or 6	Style 1	12.0			Customer says same as '13 'Berg
Husq	17-18	TE250	2 O, 2 EE, or 6	Style 5				
Husq	19	TE250i	2 O, 2 EE, or 6	Style 5				
Husq	20-24	TE250i	2 O, 2 EE, or 6	Style 1	18.0			Cut M6 bolts down to -M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	09	WR250	2 O, 2 EE, or 6	Style 1	12.0			
Husq	10	WR300	2 O, 2 EE, or 6	Style 1	12.0			
Husq	12-16	TE300	2 O, 2 EE, or 6	Style 1	14.0			
Husq	17	TE300	2 O, 2 EE, or 6	Style 5				
Husq	19	TE300i	2 O, 2 EE, or 6	Style 5				
Husq	20-24	TE300, 300 pro	2 O, 2 EE, or 6	Style 1	18.0			
Husq	18	TX300	2 O, 2 EE, or 6	Style 5				
Husq	19	TX300	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to -M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	20-22	TX300i	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to -M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	23-24	TX300	2 O, 2 EE, or 6	Style 1	19.0			See pic for hardware. '23 is the same as '24
Husq	12	TE310	2 O, 2 EE, or 6	Style 1	12.0			
Husq	15	FC350	2 O, 2 EE, or 6	Style 1	14.0			Use a small aluminum spacer on each side
Husq	16-18	FC350	2 O, 2 EE, or 6	Style 5				
Husq	20-22	FC350	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to -M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	23-24	FC350	2 O, 2 EE, or 6	Style 1				See pic for hardware. '23 is the same as '24
Husq	15, 23	FE350S	2 O, 2 EE, or 6	Style 1	14.0			Use a small aluminum spacer on each side
Husq	24	FE350S	2 O, 2 EE, or 6	Style 1	19.0			
Husq	17	FE350	2 O, 2 EE, or 6	Style 5				
Husq	19	FE350	2 O, 2 EE, or 6	Style 5				
Husq	21	FE350	2 O, 2 EE, or 6	Style 1	16.0			
Husq	20-22	FX350	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to -M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	23-24	FX350	2 O, 2 EE, or 6	Style 1	19.0			See pic for hardware. '23 is the same as '24

Make	Year	Model	Front Style	Rear Style	Adjust Tugger length to ..., inches	Extra plastic spacers?	Extra aluminum spacers?	Notes
Husq	24	TC350	2 O, 2 EE, or 6	Style 1	19.0			see pic for hardware
Husq	11	TE449	2 O, 2 EE, or 6	Style 1 special	27.0			special order - extra long Style 1
Husq	14	FC450	2 O, 2 EE, or 6	Style 1	14.0			Use a small aluminum spacer on each side
Husq	16	FC450	2 O, 2 EE, or 6	Style 1	19.5			
Husq	17	FC450	2 O, 2 EE, or 6	Style 5				
Husq	18	FC450	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to ~M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	19-22	FC450	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to ~M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	23-24	FC450	2 O, 2 EE, or 6	Style 1	19.0			See pic for hardware. '23 is the same as '24
Husq	17-18	FE450	2 O, 2 EE, or 6	Style 5				
Husq	23	FE450	2 O, 2 EE, or 6	Style 1	16.0			
Husq	24	FE450	2 O, 2 EE, or 6	Style 1	19.0			
Husq	19	FE450	2 O, 2 EE, or 6	Style 5				
Husq	18	FX450	2 O, 2 EE, or 6	Style 5				
Husq	19-22	FX450	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to ~M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	23-24	FX450	2 O, 2 EE, or 6	Style 1	19.0			See pic for hardware. '23 is the same as '24
Husq	06	TC450	2 O, 2 EE, or 6	Style 1	10.0			
Husq	05	TE450	2 O, 2 EE, or 6	Style 1	10.0			
Husq	15	FE501/501S	2 O, 2 EE, or 6	Style 1	14.0			Use a small aluminum spacer on each side
Husq	16	FE501	2 O, 2 EE, or 6	Style 1	14.0			
Husq	17-18	FE501	2 O, 2 EE, or 6	Style 5				
Husq	21-22	FE501	2 O, 2 EE, or 6	Style 1	16.0			
Husq	20-22	FE501S	2 O, 2 EE, or 6	Style 1	16.0			Cut M6 bolts down to ~M6x12 or use larger spacers inside the bushing to space out the bolt
Husq	24	FE501w, 501s	2 O, 2 EE, or 6	Style 1	19.0			
Husq	06	TC510	2 O, 2 EE, or 6	Style 1	10.0			
Husq	08	TE510	2 O, 2 EE, or 6	Style 1	10.0			
Husq	10	510TC, 510TE	2 O, 2 EE, or 6	Style 1	12.0			
Husq	08	TE610	2 O, 2 EE, or 6	Style 1	11.0			
Husq	16	Enduro 701	2 O, 2 EE, or 6	Style 1	17.0			
Kawasaki								
Kaw	06	KDX50	2 O, 2 EE, or 6	Style 1				
Kaw	07	KDX50	2 O, 2 EE, or 6	Style 3-4				
Kaw	04-'09	KX65	2 O, 2 EE, or 6	Style 1	11.0			
Kaw	16	KX65	2 O, 2 EE, or 6	Style 1	12.0			
Kaw	18-23	KX65	2 O, 2 EE, or 6	Style 1	12.0	2		Need longer bolt: M6 x 25
Kaw	04-'07	KX85	2 O, 2 EE, or 6	Style 1	13.5			
Kaw	08-09	KX85	2 O, 2 EE, or 6	Style 1	13.0			
Kaw	12	KX85	2 O, 2 EE, or 6	Style 1	11.0			
Kaw	13-16	KX85	2 O, 2 EE, or 6	Style 1	13.5			
Kaw	19-24	KX85	2 O, 2 EE, or 6	Style 1	13.0	8		Need 18 extra plastic spacers and M6 x 35 bolts
Kaw	04-'17	KX100	2 O, 2 EE, or 6	Style 1	13.0			
Kaw	14-'16	KX100	2 O, 2 EE, or 6	Style 1	14.5			
Kaw	17-21	KX100	2 O, 2 EE, or 6	Style 1	13.0	8		Need longer bolt: M6 x 30
Kaw	04-13	KLX110, KLX110L	2 O, 2 EE, or 6	Style 1	11.0			Need longer bolt: M6 x 30
Kaw	14-20	KLX110, KLX110L	2 O, 2 EE, or 6	Style 1	13.0	4		Need longer bolt: M6 x 30
Kaw	23	KX112	2 O, 2 EE, or 6	Style 1	9.0			Needs more spacers and longer bolts than come with the Tugger kit
Kaw	24	KX112	2 O, 2 EE, or 6	Style 1	13.0			
Kaw	04	KX125F	2 O, 2 EE, or 6	Style 1	11.1			
Kaw	04	KLX125	2 O, 2 EE, or 6	na	8.5			seat bracket style
Kaw	08-16	KLX140	2 O, 2 EE, or 6	Style 3-4	18.0			M8 is a tight fit through the grommet but it will work
Kaw	12-13	KLX140, 130L	2 O, 2 EE, or 6	Style 3-4	--			Must cut holes in plastic and feed Tugger through
Kaw	18-23	KLX140, 140L, 140G	2 O, 2 EE, or 6	Style 3-4	--			
Kaw	23	KLX140RF, RL	2 O, 2 EE, or 6	Style 3-4	--			Email us for comments and pics of how to install
Kaw	05	KDX200	2 O, 2 EE, or 6	Style 1	13.0			
Kaw	00-02	KDX220	2 O, 2 EE, or 6	Style 1	12.5			
Kaw	94	KDX250	2 O, 2 EE, or 6	Style 1	15.0	2		
Kaw	20	KDX230	2 O, 2 EE, or 6	Style 1	13.0			
Kaw	20	KLX230	2 O, 2 EE, or 6	Style 1	13.0			
Kaw	20-23	KLX230R(S)	2 O, 2 EE, or 6	Style 1	13.0			
Kaw	20	KLX250	2 O, 2 EE, or 6	Style 1	12.0			

Make	Year	Model	Front Style	Rear Style	Adjust Tugger length to ..., inches	Extra plastic spacers?	Extra aluminum spacers?	Notes
Kaw	98	KX250	2 O, 2 EE, or 6	Style 1	9.8			
Kaw	01	KX250	2 O, 2 EE, or 6	Style 1	9.0			
Kaw	03-21	KX250	2 O, 2 EE, or 6	Style 1	11.5			
Kaw	22-24	KX250	2 O, 2 EE, or 6	Style 1	9.5			
Kaw	04-18	KX250F	2 O, 2 EE, or 6	Style 1	11.5			
Kaw	21	KX250XC	2 O, 2 EE, or 6	Style 1	9.0			
Kaw	04	KLR250	2 O, 2 EE, or 6	Style 1	17.0			
Kaw	06	KLX250	2 O, 2 EE, or 6	Style 1				
Kaw	07-09	KLX250S,SF	2 O, 2 EE, or 6	Style 1	12.0			
Kaw	98	KLX300R	2 O, 2 EE, or 6	Style 1	12.8			
Kaw	00	KLX300R	2 O, 2 EE, or 6	Style 1	12.8			
Kaw	04	KLX300R	2 O, 2 EE, or 6	Style 1	12.8			
Kaw	20-23	KLX300R	2 O, 2 EE, or 6	Style 1	10.0			
Kaw	03	KLX400S	2 O, 2 EE, or 6	Style 1	11.0			
Kaw	08	KLX450R	2 O, 2 EE, or 6	Style 1	11.0			
Kaw	06-18	KX450F	2 O, 2 EE, or 6	Style 1	11.5			
Kaw	19-23	KX450	2 O, 2 EE, or 6	Style 1	9.5			
Kaw	21-23	KX450X	2 O, 2 EE, or 6	Style 1	9.5			
Kaw	00	KX500	2 O, 2 EE, or 6	Style 1	12.0			
Kaw	01	KX500	2 O, 2 EE, or 6	Style 1	14.5			
Kaw	04	KLR650	2 O, 2 EE, or 6	na				
KTM								
KTM	99-17	50 (all)	2 O, 2 EE, or 6	Style 3-4				
KTM	18-23	50SX	2 O, 2 EE, or 6	Style 3-4				
KTM	24	sxEs	2 O, 2 EE, or 6	Style 3-4				
KTM	02-14	65SX	2 O, 2 EE, or 6	Style 3-4				remove seat to install
KTM	17-18	65SX	2 O, 2 EE, or 6	Style 1	17.0			
KTM	19	65SX	2 O, 2 EE, or 6	Style 3-4				
KTM	20	65SX	2 O, 2 EE, or 6	--				no obvious clean solution - ingenuity required...
KTM	08-09	65XC	2 O, 2 EE, or 6	Style 3-4				remove seat to install
KTM	02-12	85SX	2 O, 2 EE, or 6	Style 3-4				
KTM	13-17	85SX	2 O, 2 EE, or 6	Style 1	13.0			
KTM	20-24	85SX	2 O, 2 EE, or 6	Style 1	16.0			
KTM	08	85XC	2 O, 2 EE, or 6	Style 3-4	11.0			open end version
KTM	06-09	105SX	2 O, 2 EE, or 6	Style 3-4	12.0			remove fender to install
KTM	08	105XC	2 O, 2 EE, or 6	Style 3-4	11.0			remove fender to install
KTM	02-03	125SX	2 O, 2 EE, or 6	Style 1				
KTM	04-06	125SX	2 O, 2 EE, or 6	Style 3-4				
KTM	07-13	125SX	2 O, 2 EE, or 6	Style 1	15.0			
KTM	17	125SX	2 O, 2 EE, or 6	Style 1	17.5			
KTM	20-22	125SX	2 O, 2 EE, or 6	Style 1	22.0			
KTM	21	125XC	2 O, 2 EE, or 6	Style 1	22.0			
KTM	24	125XC	2 O, 2 EE, or 6	Style 3-4				
KTM	07-08	144SX	2 O, 2 EE, or 6	Style 1	15.0			
KTM	09	150SX	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-14	150SX	2 O, 2 EE, or 6	Style 1	14.0			
KTM	17-18	150SX	2 O, 2 EE, or 6	Style 1	18.0			
KTM	19	150SX	2 O, 2 EE, or 6	Style 1	22.0			
KTM	10-11	150XC	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-14	150XC	2 O, 2 EE, or 6	Style 1	14.0			
KTM	18-19	150XC-W	2 O, 2 EE, or 6	Style 1	18.0			
KTM	22	150XC-W	2 O, 2 EE, or 6	Style 1	21.0			
KTM	24	150XC-W	2 O, 2 EE, or 6	Style 3-4				
KTM	01-03	200EXC	2 O, 2 EE, or 6	Style 1	10.5			
KTM	04-06	200EXC	2 O, 2 EE, or 6	Style 1	12.8			
KTM	04-05	200SX	2 O, 2 EE, or 6	Style 3-4				
KTM	06	200 XC-W	2 O, 2 EE, or 6	Style 1				
KTM	06-07	200 XC	2 O, 2 EE, or 6	Style 1	13.0			
KTM	08-11	200 XC, XC-W	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-15	200 XC, XC-W	2 O, 2 EE, or 6	Style 1	14.0			
KTM	22	200XC-W	2 O, 2 EE, or 6	Style 1	21.0			
KTM	15	250 Freeride	2 O, 2 EE, or 6	Style 1	21"			
KTM	17	250 Freeride	2 O, 2 EE, or 6	Style 1	21"			
KTM	01	250EXC	2 O, 2 EE, or 6	Style 1	10.5			
KTM	04-06	250EXC	2 O, 2 EE, or 6	Style 1	12.8			

Make	Year	Model	Front Style	Rear Style	Adjust Tugger length to ... inches	Extra plastic spacers?	Extra aluminum spacers?	Notes
KTM	08	250EXC	2 O, 2 EE, or 6	Style 1	15.0			
KTM	18	250EXC-F	2 O, 2 EE, or 6	Style 1	18.0			
KTM	03-06	250SX	2 O, 2 EE, or 6	Style 3-4				
KTM	07-11	250SX	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-16	250SX	2 O, 2 EE, or 6	Style 1	14.0			
KTM	19-21	250SX	2 O, 2 EE, or 6	Style 1	22.0			
KTM	23-24	250SX	2 O, 2 EE, or 6	Style 3-4				
KTM	06	250SXF	2 O, 2 EE, or 6	Style 3-4	13.0			NO tapped holes in subframe stubs; can't use Style 1
KTM	07-11	250SXF	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-15	250SXF	2 O, 2 EE, or 6	Style 1	14.0			
KTM	16-18	250 SX-F	2 O, 2 EE, or 6	Style 1	18.0			
KTM	19-20	250 SX-F	2 O, 2 EE, or 6	Style 1	22.0			
KTM	23-24	250 SX-F	2 O, 2 EE, or 6	Style 3-4				
KTM	08-11	250XC	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-14	250XC	2 O, 2 EE, or 6	Style 1	14.0			
KTM	18	250XC	2 O, 2 EE, or 6	Style 1	18.0			
KTM	19	250XC	2 O, 2 EE, or 6	Style 1	22.0			
KTM	23-24	250XC	2 O, 2 EE, or 6	Style 3-4				
KTM	20	250XC tpi	2 O, 2 EE, or 6	Style 1	22.0			
KTM	07-11	250XC-F	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-14	250XC-F	2 O, 2 EE, or 6	Style 1	14.0			
KTM	17-18	250XC-F	2 O, 2 EE, or 6	Style 1	17.5			
KTM	19-20	250XC-F	2 O, 2 EE, or 6	Style 1	22.0			
KTM	23-24	250XC-F	2 O, 2 EE, or 6	Style 3-4				
KTM	07	250XCF-W	2 O, 2 EE, or 6	Style 1	12.0			
KTM	08-11	250XCF-W	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-15	250XCF-W	2 O, 2 EE, or 6	Style 1	14.0			
KTM	23	250XCF-W	2 O, 2 EE, or 6	Style 3-4				
KTM	07-11	250XC-W	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-16	250XC-W	2 O, 2 EE, or 6	Style 1	14.0			
KTM	17-19	250XC-W	2 O, 2 EE, or 6	Style 1	18.0			
KTM	20-23	250XC-W	2 O, 2 EE, or 6	Style 1	22.0			
KTM	24	250XC-W	2 O, 2 EE, or 6	Style 3-4				
KTM	04-06	300MXC	2 O, 2 EE, or 6	Style 1	13.0			
KTM	04-06	300EXC	2 O, 2 EE, or 6	Style 1	13.0			
KTM	08	300EXC	2 O, 2 EE, or 6	Style 1	15.0			
KTM	06-07	300XC	2 O, 2 EE, or 6	Style 1	12.8			
KTM	08-11	300XC	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-16	300XC	2 O, 2 EE, or 6	Style 1	14.0			
KTM	17-18	300XC	2 O, 2 EE, or 6	Style 1	18.0			
KTM	19	300XC	2 O, 2 EE, or 6	Style 1	22.0			
KTM	20-22	300XC	2 O, 2 EE, or 6	Style 1	22.0			
KTM	23-24	300XC	2 O, 2 EE, or 6	Style 3-4				
KTM	06-07	300XC-W	2 O, 2 EE, or 6	Style 1	12.8			
KTM	09-11	300XC-W	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-16	300XC-W	2 O, 2 EE, or 6	Style 1	14.0			
KTM	17-19	300XC-W	2 O, 2 EE, or 6	Style 1	18.0			
KTM	20-23	300XC-W	2 O, 2 EE, or 6	Style 1	22.0			
KTM	24	300XC-W	2 O, 2 EE, or 6	Style 3-4				
KTM	11	350 (all)	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-15	350 (all)	2 O, 2 EE, or 6	Style 1	14.0			
KTM	16	350 EXC-F	2 O, 2 EE, or 6	Style 1	14.0			
KTM	18	350 EXC-F	2 O, 2 EE, or 6	Style 1	18.0			
KTM	21-23	350 EXC-F	2 O, 2 EE, or 6	Style 1	22.0			
KTM	24	350 EXC-F	2 O, 2 EE, or 6	Style 3-4				
KTM	16-18	350 SX-F	2 O, 2 EE, or 6	Style 1	18.0			
KTM	19-22	350 SX-F	2 O, 2 EE, or 6	Style 1	22.0			
KTM	24	350 SX-F	2 O, 2 EE, or 6	Style 3-4				
KTM	16-18	350 XC-F	2 O, 2 EE, or 6	Style 1	18.0			
KTM	19-22	350 XC-F	2 O, 2 EE, or 6	Style 1	22.0			
KTM	23-24	350 XC-F	2 O, 2 EE, or 6	Style 3-4				
KTM	16	350 XCF-W	2 O, 2 EE, or 6	Style 1	14.0			
KTM	20	350 XCF-W	2 O, 2 EE, or 6	Style 1	22.0			
KTM	99	380EXC	2 O, 2 EE, or 6	Style 1	11.0			
KTM	01	400SX	2 O, 2 EE, or 6	Style 1	10.5			

Make	Year	Model	Front Style	Rear Style	Adjust Tugger length to ... inches	Extra plastic spacers?	Extra aluminum spacers?	Notes
KTM	01-02	400E/MXC	2 O, 2 EE, or 6	Style 1	10.5			
KTM	04-07	450 (all)	2 O, 2 EE, or 6	Style 1	14.0			
KTM	08-11	450 (all)	2 O, 2 EE, or 6	Style 1	15.0			
KTM	12-15	450 (all)	2 O, 2 EE, or 6	Style 1	14.0			
KTM	03	450 EXC	2 O, 2 EE, or 6	Style 1	10.5			
KTM	18	450 EXC-F	2 O, 2 EE, or 6	Style 1	18.0			
KTM	03-06	450SX	2 O, 2 EE, or 6	Style 3-4				
KTM	07-11	450 SX-F	2 O, 2 EE, or 6	Style 1	15.0			
KTM	20-21	450 SX-F	2 O, 2 EE, or 6	Style 1	21.0			
KTM	23	450 SX-F	2 O, 2 EE, or 6	none				no clean solution - ingenuity required...
KTM	24	450 SX-F	2 O, 2 EE, or 6	Style 3-4				
KTM	16	450 XC-W	2 O, 2 EE, or 6	Style 1	14.0			
KTM	17-18	450 XC-F	2 O, 2 EE, or 6	Style 1	18.0			
KTM	19-22	450 XC-F	2 O, 2 EE, or 6	Style 1	21.0			
KTM	23-24	450 XC-F	2 O, 2 EE, or 6	Style 3-4				
KTM	23	450 XCF-W	2 O, 2 EE, or 6	Style 1	21.0			
KTM	24	450 XCF-W	2 O, 2 EE, or 6	Style 3-4				
KTM	06-07	450SMR	2 O, 2 EE, or 6	Style 3-4	13.0			
KTM	12-16	500 (all)	2 O, 2 EE, or 6	Style 1	14.0			
KTM	18	500 EXC-F	2 O, 2 EE, or 6	Style 1	18.0			
KTM	20-22	500 EXC-F	2 O, 2 EE, or 6	Style 1	22.0			
KTM	24	500 EXC-F	2 O, 2 EE, or 6	Style 3-4				
KTM	22	500 XCF-W	2 O, 2 EE, or 6	Style 1	21.0			
KTM	24	500 XW-F	2 O, 2 EE, or 6	Style 3-4				
KTM	08-09	505XCF	2 O, 2 EE, or 6	Style 1	15.0			
KTM	02	520EXC	2 O, 2 EE, or 6	Style 1	10.5			
KTM	01	520EXC	2 O, 2 EE, or 6	Style 1	10.5			
KTM	04-05	525MXC	2 O, 2 EE, or 6	Style 1	14.0			
KTM	04-07	525EXC	2 O, 2 EE, or 6	Style 1	13.5			
KTM	07	525XC	2 O, 2 EE, or 6	Style 1	13.0			
KTM	06	525SX	2 O, 2 EE, or 6	Style 3-4	14.0			NO tapped holes in subframe stubs; can't use Style 1
KTM	08-11	530 (all)	2 O, 2 EE, or 6	Style 1	15.0			
KTM	06	560 SMR	2 O, 2 EE, or 6	Style 3-4				
KTM	96-04	LC4	2 O, 2 EE, or 6	Style 1	15.5"			
KTM	04	625 SXC	2 O, 2 EE, or 6	Style 1	15.5"			
KTM	02	LC4-640E	2 O, 2 EE, or 6	Style 1	18.5"			
KTM	06-07	All XC	2 O, 2 EE, or 6	Style 1	14.0			
KTM	06-07	All XC-W	2 O, 2 EE, or 6	Style 1	14.0			
KTM	09-16	690 Enduro	2 O, 2 EE, or 6	none				no obvious clean solution - ingenuity required...
KTM	04	950 Adv	2 O, 2 EE, or 6	Style 1	18"	12		
LEM								
LEM	05	RX3	2 O, 2 EE, or 6	Style 1	10.0			
Sherco								
Sherco	2017	300 SE-R	2 O, 2 EE, or 6	Style 1	18.0			
Sherco	20	300 SC	2 O, 2 EE, or 6	Style 1				
Sherco	05-08	450 enduro	2 O, 2 EE, or 6	Style 1				
Sherco	05-08	510 enduro	2 O, 2 EE, or 6	Style 1				
Sherco	18-19	125 to 500 SC & SE	2 O, 2 EE, or 6	Style 1	15.0			
Sherco	20-23	FSE300 Factory	2 O, 2 EE, or 6	Style 1	16.0			
Sherco	20	500 SE-F Factory	2 O, 2 EE, or 6	Style 1	16.0			
Surron								
Sur	23	Ultra Bee	2 O, 2 EE, or 6	Style 1	16.0			
Suzuki								
Suz	07	JR50	2 O, 2 EE, or 6	Style 3-4				
Suz	03, 04	RM65	2 O, 2 EE, or 6	Style 1	10.8	12		
Suz	19	DRZ50	2 O, 2 EE, or 6	Style 3-4				
Suz	08-18	DRZ70	2 O, 2 EE, or 6	Style 3-4				With M8 bolts it's a tight fit but will work
Suz	04	RM80	2 O, 2 EE, or 6	Style 1	10.4			
Suz	07-23	RM85, 85L	2 O, 2 EE, or 6	Style 1	11.0			
Suz	04	DRZ110	2 O, 2 EE, or 6	Style 1	10.8			
Suz	04	DRZ125	2 O, 2 EE, or 6	na	8.8			seat bracket style
Suz	04-06	DRZ125L	2 O, 2 EE, or 6	na				seat bracket style

Make	Year	Model	Front Style	Rear Style	Adjust Tugger length to ... inches	Extra plastic spacers?	Extra aluminum spacers?	Notes
Suz	07	DRZ125L	2 O, 2 EE, or 6	Style 3-4				
Suz	08-23	DRZ125L	2 O, 2 EE, or 6	Style 1	10.0			
Suz	04	RM125	2 O, 2 EE, or 6	Style 1	10.3			
Suz	06	RM125	2 O, 2 EE, or 6	Style 1	10.0			
Suz	15-19	DR200S	2 O, 2 EE, or 6	Style 1	16.0			
Suz	98	RM250	2 O, 2 EE, or 6	Style 1	10.3			
Suz	00	RM250	2 O, 2 EE, or 6	Style 1	10.3			
Suz	04-08	RM250	2 O, 2 EE, or 6	Style 1	10.5			
Suz	04-24	RMZ250	2 O, 2 EE, or 6	Style 1	11.0			
Suz	07	DRZ250	2 O, 2 EE, or 6	na	na			
Suz	01	DRZ400S	2 O, 2 EE, or 6	Style 1	11.0			
Suz	04-07	DRZ400S	2 O, 2 EE, or 6	Style 1	11.0			
Suz	00-04	DRZ400E	2 O, 2 EE, or 6	Style 1	10.5			
Suz	09	DRZ400	2 O, 2 EE, or 6	Style 1	11.0			
Suz	09-16	DRZ400SM	2 O, 2 EE, or 6	Style 1	11.0			Could also mount to brackets farther back than the seat - 15" in that case
Suz	19	DRZ400	2 O, 2 EE, or 6	Style 1	11.0			Could also mount to brackets farther back than the seat - 15" in that case
Suz	09	DRZ400Dual	2 O, 2 EE, or 6	Style 1	11.0			
Suz	17-18	RMX450Z	2 O, 2 EE, or 6	Style 1	11.0			
Suz	06-11	RMZ450	2 O, 2 EE, or 6	Style 1	11.0			
Suz	12-17	RMZ450	2 O, 2 EE, or 6	Style 1	12.5			
Suz	18-23	RMZ450	2 O, 2 EE, or 6	Style 1	10.5			
Suz		DR650	2 O, 2 EE, or 6	Style 1	15.0			
TM								
TM	15	85MX	2 O, 2 EE, or 6	Style 1	11.0			
TM	07-09	250 enduro	2 O, 2 EE, or 6	Style 1	14.5			
TM	00	300 EN	2 O, 2 EE, or 6	Style 1	10.0			
TM	21	EN300FI	2 O, 2 EE, or 6	Style 1	10.0			2021 TM EN300FI
Yamaha								
Yam	08-22	PW50	2 O, 2 EE, or 6	Style 3-4				
Yam	05-23	TTR50	2 O, 2 EE, or 6	Style 3-4				
Yam	81	PW80	2 O, 2 EE, or 6	Style 1				
Yam	04-06	PW80	2 O, 2 EE, or 6	Style 3-4				
Yam	04-15	YZ85	2 O, 2 EE, or 6	Style 1	10.5			
Yam	22	YZ85	2 O, 2 EE, or 6	Style 3-4				Have pics
Yam	04	TTR90	2 O, 2 EE, or 6	Style 3-4				
Yam	08	TTR110	2 O, 2 EE, or 6	Style 1	12.0			
Yam	09	TTR110	2 O, 2 EE, or 6	Style 3-4				
Yam	12	TTR110	2 O, 2 EE, or 6	Style 1	12.0			
Yam	16-24	TTR110	2 O, 2 EE, or 6	Style 3-4				
Yam	01-07	TTR125, TTR125L	2 O, 2 EE, or 6	Style 1	10.5			
Yam	08-12	TTR125, TTR125L	2 O, 2 EE, or 6	Style 1	11.0			
Yam	13-18	TTR125, TTR125L	2 O, 2 EE, or 6	Style 1	11.0			Right side mounts under plastic; left side needs 8 plastic spacers and M8x35 bolt
Yam	19	TTR125, TTR125L	2 O, 2 EE, or 6	Style 3-4				
Yam	22	TTR125, TTR125L	2 O, 2 EE, or 6	none				no clean solution - ingenuity required...
Yam	24	TTR125	2 O, 2 EE, or 6	Style 1	11"			Probably want to cut away some plastic on the right side
Yam	00-01	YZ125	2 O, 2 EE, or 6	Style 1	8.8			
Yam	02-07	YZ125	2 O, 2 EE, or 6	Style 1	10.5			
Yam	20	YZ125X	2 O, 2 EE, or 6	Style 1	10.0			
Yam	24	YZ125X	2 O, 2 EE, or 6	Style 1	15.0			Left side bolts underneath, right side on top
Yam	09	TW200	2 O, 2 EE, or 6	Style 3-4				Need to double check if M6 or M8 bolts
Yam	04	XT225	2 O, 2 EE, or 6	Style 1	14.3			
Yam	04	TTR225	2 O, 2 EE, or 6	Style 1	15.5			frame has M8 threaded holes to use
Yam	06-24	TTR230	2 O, 2 EE, or 6	Style 1	9.5			
Yam	05	TTR250	2 O, 2 EE, or 6	3-4 special				Special, longer style 3-4; 28" 'tween grommets
Yam	02-06	WR250F	2 O, 2 EE, or 6	Style 1	9.5			
Yam	07-12	WR250F	2 O, 2 EE, or 6	Style 1	10.5			
Yam	15-22	WR250F	2 O, 2 EE, or 6	Style 1	10.0			
Yam	08-09	WR250R	2 O, 2 EE, or 6	Style 3-4				street legal; uses two seat mounting bolts underneath

Make	Year	Model	Front Style	Rear Style	Adjust Tugger length to ..., inches	Extra plastic spacers?	Extra aluminum spacers?	Notes
Yam	12	WR250R	2 O, 2 EE, or 6	N/A				Customer reports neither Style 1 nor Style 3-4 work
Yam	14-16	WR250R	2 O, 2 EE, or 6	Style 3-4				Customer very happy - see pics
Yam	08-09	WR250X	2 O, 2 EE, or 6	Style 3-4				need to trim the plastic a bit
Yam	96	YZ250	2 O, 2 EE, or 6	Style 1	10.0			
Yam	99	YZ250	2 O, 2 EE, or 6	Style 1	9.0			
Yam	01	YZ250	2 O, 2 EE, or 6	Style 1	8.5			
Yam	02-06	YZ250	2 O, 2 EE, or 6	Style 1	10.0			
Yam	17	YZ250	2 O, 2 EE, or 6	Style 1	10.5			
Yam	01-12	YZ250F	2 O, 2 EE, or 6	Style 1	10.0			
Yam	13-18	YZ250F	2 O, 2 EE, or 6	Style 1	10.0			
Yam	19-24	YZ250F	2 O, 2 EE, or 6	Style 1	9.5			
Yam	15-24	YZ250FX	2 O, 2 EE, or 6	Style 1	10.0			
Yam	22	YZ250X	2 O, 2 EE, or 6	Style 1	10.0			
Yam	24	YZ250X	2 O, 2 EE, or 6	Style 1	15.0			Left side bolts underneath, right side on top
Yam	09	XT250	2 O, 2 EE, or 6	Style 1	11.0			replaces existing handles - have to trim the plastic a bit
Yam	98	YZ400F	2 O, 2 EE, or 6	Style 1	8.6			
Yam	01	WR426F	2 O, 2 EE, or 6	Style 1	8.8			
Yam	02	YZ426F	2 O, 2 EE, or 6	Style 1	8.6			
Yam	04-07	WR450F	2 O, 2 EE, or 6	Style 1	9.1			
Yam	08-17	WR450F	2 O, 2 EE, or 6	Style 1	10.5			
Yam	20-22	WR450F	2 O, 2 EE, or 6	Style 1	9.0			
Yam	04-06	YZ450F	2 O, 2 EE, or 6	Style 1	9.1			
Yam	08-12	YZ450F	2 O, 2 EE, or 6	Style 1	10.0			
Yam	13-17	YZ450F	2 O, 2 EE, or 6	Style 1	10.0			
Yam	18	YZ450F	2 O, 2 EE, or 6	Style 1	9.0			
Yam	19-24	YZ450F	2 O, 2 EE, or 6	Style 1	9.5			
Yam	18	YZ450FX	2 O, 2 EE, or 6	Style 1	10.5			
Yam	19-20	YZ450FX	2 O, 2 EE, or 6	Style 1	9.5			
Yam	84	IT490	2 O, 2 EE, or 6	Style 1	20.5			
Yam	92	WR500	2 O, 2 EE, or 6	Style 1	17.2			